

2010 Porsche Cup Car Grill Screen Installation Tips



The grill screen sets for 2010 cup car nose are made of all stainless steel and the side screens cam lock. It comes with backing plates with cam lock buckets installed.

1. You will want to remove the plastic inner liner parts.
2. The center screen is very straight forward as you can see.
3. On the side screen, I start with the outside pins. I drill pilot holes then go up to 13/64.
4. Then lay down the camlock end of the screen and mark. Drill pilot hole then drill up to 3/8. Then line up the camlock bucket mounting plate and drill through the back. Rivet through the front and that's it.

Now, I have sent camlocks that I have found that work with the urethane. If you have a carbon nose, it may require a shorter stud length camlock. I sent 12 -0.940 2700 series.

5. Finally, you will have to do a small amount of clearance to the plastic inserts.

Capital City Motorsports Inc.
Sacramento, California
916.296.5238

garybiehl@earthlink.net
capitalcitymotorsports.us

